

TABLE OF CONTENTS

TABLE OF CONTENTS	i
LIST OF FIGURES	ii
LIST OF TABLES.....	ii
1. DESCRIPTION	1
1.1. FUNCTIONAL DESCRIPTION.....	1
2. SPECIFICATIONS.....	4
2.1. EXTERNAL COMPONENTS	4
2.2. INTERNAL COMPONENTS.....	5
2.3. CHARACTERISTICS OF THE SIGNALS	6
2.4. GENERAL	6
2.5. POWER REQUIREMENTS.....	6
3. OPERATING MODES.....	10
3.1. GENERAL INFORMATION.....	10
3.2. POWER-ON / RESET STATUS.....	10
3.3. BUFFERING LOGIC.....	11
3.3.1. CIRCULAR BUFFER LENGTH.....	11
3.3.2. NUMBER OF SAMPLES TO ACQUIRE	11
3.3.3. ALMOST EMPTY FLAG	12
3.3.4. ALMOST FULL FLAG	12
3.4. PROGRAMMING THE MODULE	12
3.5. ACQUISITION SEQUENCE.....	14
3.6. CLOCK OPERATION	14
3.7. STOP LOGIC	15
3.8. BUSY LOGIC.....	15
3.9. TIME TAG COUNTER	16
4. VME INTERFACE.....	17
4.1. ADDRESSING CAPABILITY	17
4.2. OUTPUT BUFFER REGISTER.....	19
4.3. SAMPLE REGISTER.....	19
4.4. ACCEPTED EVENTS COUNTER	20
4.5. REJECTED EVENTS COUNTER	20
4.6. CONTROL & STATUS REGISTER.....	21
4.7. FIFO SETTING REGISTER.....	22
4.8. UPDATE FIFO SET REGISTER	22
4.9. RESET REGISTER	22
4.10. SOFTWARE STOP REGISTER.....	22
APPENDIX A: ELECTRICAL DIAGRAMS	A.1

LIST OF FIGURES

Fig. 1.1: V676 Block Diagram	3
Fig. 2.1: V676 Front Panel.....	7
Fig. 2.2: V676 Components Locations	8
Fig. 2.3: Mod. V676 Jumpers Settings.....	9
Fig. 3.1: Mod. V676 Buffer Flag Programming Words.....	13
Fig. 3.2: Mod. V676 Clock Buffering Scheme	14
Fig. 3.3: Mod. V676 STOP Logic.....	15
Fig. 4.1: Mod. V676 Base Address Setting	18
Fig. 4.2: Mod. V676 Header Structure	19
Fig. 4.3: Mod. V676 Data Structure	19
Fig. 4.4: Mod. V676 Sample Register	19
Fig. 4.5: Mod. V676 Accepted Events Register.....	20
Fig. 4.6: Mod. V676 Rejected Events Register.....	20
Fig. 4.7: Mod. V676 Control & Status Register	21
Fig. 4.8: Mod. V676 FIFO Setting Register	22
Fig. 4.9: Mod. V676 Software Stop Register	22

LIST OF TABLES

Table 4.1: Address Map for the Mod. V676.....	17
Table 4.2: Mod. V676 Control Bits.....	21

1. DESCRIPTION

1.1. FUNCTIONAL DESCRIPTION

The CAEN Model V676 is a 3 CHANNEL 40 MHz ADC housed in a 1-unit wide VME module, realized with two independent boards (ADC and FIFO) connected via two 68-pin connectors (a functional block diagram is shown in Fig. 1.1). The task of this module is to store in an output buffer a certain number of ADC converted words (10 bit per channel) that belong to a temporal window placed around a STOP signal.

The module houses three FERMI Analog ASICs (housing a Compressor and an ADC) and two buffer FIFOs (circular and output, 4K x 32 bits each). At each pulse of the external or internal CLOCK (40 MHz maximum frequency) the input data are converted and stored in the circular buffer (30 bit, 10 per channel); when the programmed buffer length is reached, each oldest datum is lost with the storage of each new input datum.

Each pulse of the External or the Internal CLOCK increments a 30 bit Time Tag Counter. This Counter is set to 0 by an external CLEAR signal.

At the arrival of an external or software STOP, the data coming from the circular buffer are transferred to an Output buffer with a Header containing the Time Tag Counter value at the occurrence of the STOP signal: the User can program via VME the number of samples before the STOP (i.e. the Circular Buffer length) and the total number of samples to be transferred in the Output Buffer (length of the temporal window).

The STOP signal also increments an Event Counter whose content is stored in a further register (12 bit). If the STOP signal occurs during a data transfer from the Circular to the Output Buffer, or if the Output Buffer is full, the data transfer will not occur and a "Rejected Event" Counter will be incremented (also available in a 12 bit register).

The status of the module is available on a Status Register for readout via VME.

A front panel LED (DTACK) lights up each time the module generates the VME signal DTACK. The data contained in the FIFO buffers are accessible via VME either in single word or in Block Transfer readout.

The Model V676 uses the P1 and P2 connectors of VME.

The module works in A24/A32 mode; the recognized Address Modifier codes are:


AM= %3D	standard supervisor data access;
AM= %39	standard user data access;
AM= %0D	extended supervisor data access;
AM= %09	extended user data access;
AM = %3F	standard supervisor block transfer;
AM = %3B	standard user block transfer;
AM = %0F	extended supervisor block transfer;
AM = %0B	extended user block transfer.

The module's Base Address is fixed by 4 internal rotary switches housed on a piggy-back board plugged into the main printed circuit boards. The Base Address can be selected in the range:

%00 0000 <-> %FF 0000	A24 mode.
%0000 0000 <-> %FFFF 0000	A32 mode.

The Registers are accessed in D16 mode; the readout of the Output Buffer is available in D32 and BLT32 modes only.

(Developed in collaboration with CERN in the frame of the FERMI-RD16 Collaboration)

**Fig. 1.1: V676 Block Diagram**

2. SPECIFICATIONS

2.1. EXTERNAL COMPONENTS

(Refer to Fig. 2.1)

CONNECTORS

- N. 2, "STOP", input connectors, LEMO 00 type; two bridged connectors (for daisy chaining) for the STOP signal.
- N. 2, "CLK", input connectors, LEMO 00 type; two bridged connectors (for daisy chaining) for the external CLOCK signal.
- N. 2, "CLR", input connectors, LEMO 00 type; two bridged connectors (for daisy chaining) for the external CLEAR signal.
- N. 1, "BUSY", output connector, LEMO 00 type, for the BUSY signal.
- N. 6, "CH1..CH3 +/-", input connectors, SMC R112305 type. Connectors for the INPUT signals.

DISPLAYS

- N. 1, "DTACK", green LED, VME selected; it lights up during a VME access.
- N. 1, "BUSY", red LED; it lights up when the module is Busy.

2.2. INTERNAL COMPONENTS

(Refer to Fig. 2.2)

CONNECTORS

- N. 4, connectors, 2*D3467 and 2*D3567 Type (CERN SCEM 09.55.21.368.0 and 09.55.21.568.4). Connectors for the FIFO and ADC boards connection.

SWITCHES, JUMPERS

(Refer to Fig. 2.2, 2.3)

N. 4, rotary switches for the module's VME Base Address selection.

N. 1, "S0", DIP switch, for the External / Internal (EXT/INT) Clock selection.

N. 2, "S1", DIP switches, to insert a division by 2 (DIV2) of the CLOCK frequency for each inserted DIP switch (both inserted = CLOCK/4: Clock is divided by 4).

- +12V JMP Jumper inserted, connects the analog part to the +12V power supply;
- -12V JMP Jumper inserted, connects the analog part to the -12V power supply;
- AGND JMP Jumper inserted, connects the analog ground to the digital ground;
- CENT_J Jumper must be inserted in the left position;

(in the following, only one representative for channel 1 is mentioned; channel 2 and 3 jumpers are numbered accordingly, e.g., JM_ADIN2 or JM_ADIN3)

- JM_ADIN1 Connects the ADC +input to a signal source, either the level shifter output (the upper location) or directly to the input connector for using only the ADC and not the compressor and level shifter (the lower location);
- JG_ADIN1 Connects the ADC -input to either the AGND (the upper location, for using the ADC only) or to the base line control circuitry (the lower location, for using the compressor and the level shifter);
- +JMP_C1 Single ended (right position) or differential (left) selection;
- -JMP_C1 Single ended (right position) or differential (left) selection;
- +J_INC1 Negative (left location) or positive (right location) going signal when using the compressor in single ended mode;
- -J_INC1 Positive (left location) or negative (right location) going signal when using the compressor in single ended mode;
- J_10.5V1 Connects the +10.5V power for the compressor to the internal (upper position) or external (lower position) power supply. To be set in the lower position;
- STR100 Positive input signal routing. Up for ADC directly, left for single ended, and right for differential input signal.

2.3. CHARACTERISTICS OF THE SIGNALS

INPUTS:

- ANALOG INPUTS: With compressor inserted:
 - 2 V single ended, positive or negative pulses
(selection via internal jumpers, see Fig. 2.3);
 - ± 2 V differential; 50 Ω impedance (referred to ground).Without compressor inserted:
 - 2 V single ended, positive pulses
(selection via internal jumpers, see Fig. 2.3);
 - 50 Ω impedance (referred to ground);
- STOP: Std. NIM level, high impedance (1 k Ω); input bridged connectors.
Min. width: 1 Divided Clock cycle (i.e. at the frequency on the output of the Clock Division stage, see Fig. 3.2).
Min. time between 2 STOP pulses: 4 Divided Clock cycles
(i.e. at the frequency on the output of the Clock Division stage).
- CLOCK: Std. NIM level, high impedance (1 k Ω); input bridged connectors.
Maximum frequency: 40 MHz; Duty cycle: 50%.
- CLEAR: Std. NIM level, high impedance (1 k Ω); input bridged connectors.
Min. width: 1 Divided Clock cycle (i.e. at the frequency on the output of the Clock Division stage, see Fig. 3.2).

OUTPUTS:


- BUSY: Std. NIM level on 50 Ω impedance

2.4. GENERAL

- RESOLUTION: 10 bits;
- DYNAMIC RANGE: 15 bits (with compressor inserted);
- INPUT SENSITIVITY: 100 μ V/count at low input amplitude (compressor inserted);
2 mV/count (without compressor).
- DIFFERENTIAL NONLINEARITY (ADC ONLY): $< \pm 0.5$ LSB;
- INTEGRAL NONLINEARITY (ADC ONLY): $< \pm 1$ LSB;
- ANALOG BANDWIDTH: 20 MHz.

2.5. POWER REQUIREMENTS

+ 12 V	0.5 A
- 12 V	0.3 A
+ 5 V	1.5 A

**Fig. 2.1: Mod. V676 Front Panel**





Fig. 2.2: Mod. V676 Components Locations

**Single ended with no compressor:**

STR100	up
JM_ADIN1	down
JG_ADIN1	up

Single ended with compressor:

STR100	left
JM_ADIN1	up
JG_ADIN1	down
+JMP_C1	right
-JMP_C1	right
Single ended with compressor configuration options:	
Positive signals:	
+J_INC1	right
-J_INC1	left
Negative signals:	
+J_INC1	left
-J_INC1	right

Differential with compressor:

STR100	right
JM_ADIN1	up
JG_ADIN1	down
+JMP_C1	left
-JMP_C1	left

Fig. 2.3: Mod. V676 Jumpers Settings

3. OPERATING MODES

3.1. GENERAL INFORMATION

The CAEN Model V676 is a 3 CHANNEL 40 MHz ADC housed in a 1-unit wide VME module. The task of this module is to store in an output buffer a certain number of ADC converted words (10 bit per channel) that belong to a temporal window placed around a STOP signal.

The module houses three FERMI Analog ASICs (housing a Compressor and an ADC) and two buffer FIFOs (circular and output, 4K x 32 bits each). At each pulse of the external or internal CLOCK (40 MHz maximum frequency) the input data are converted and stored in the circular buffer (30 bit, 10 per channel); when the programmed buffer length is reached, each oldest datum is lost with the storage of each new input datum.

Each pulse of the External or the Internal Divided CLOCK (see §3.6) increments a 30 bit Time Tag Counter. This Counter is set to 0 by an external CLEAR signal.

At the arrival of an external or software STOP , the data coming from the circular buffer are transferred to an Output buffer with a Header containing the Time Tag Counter value: the User can program via VME the number of samples before the STOP (i.e. the Circular Buffer length) and the total number of samples to be transferred in the Output Buffer (length of the temporal window).

The STOP signal also increments an Event Counter whose content is stored in a further register (12 bit). If the STOP signal occurs during a data transfer from the Circular to the Output Buffer, or if the Output Buffer is full, the data transfer will not occur and a "Rejected Event" Counter will be incremented (also available in a 12 bit register).

The status of the module is available on a Status Register for readout via VME.

3.2. POWER-ON / RESET STATUS

At Power-ON, the module is in the following status:

1. the Time Tag Counter is set to 0 (see § 4.2);
2. the Accepted Events Counter is set to 0 (see § 4.4);
3. the Rejected Events Counter is set to 0 (see § 4.5);
4. the Sample Register is set to 1024 (see § 4.3);
5. the Circular and the Output Buffers are cleared;
6. the module is set to Buffers Programming mode (see § 4.6).

The VME Reset (access to address Base + %10) and the generation of the VME signal SYSRES perform the same actions.

At Power-ON or after a reset the Buffers must thus be initialized (see § 3.3).

3.3. BUFFERING LOGIC

The User can program via VME the number of samples before the STOP (i.e. the Circular Buffer length), the total number of samples to be transferred in the Output Buffer (length of the temporal window) and two flags (Almost Empty, Almost Full) that allow to manage the data flow to and from the Output Buffer.

Here below is described the logic of this buffering scheme for each programmable variable with some suggested operations for a correct setting.

3.3.1. CIRCULAR BUFFER LENGTH

When the module is in acquisition mode it converts and stores in the Circular Buffer the incoming input signals. Once a STOP signal occurs, the Circular Buffer will already contain a certain number of samples that the User may wish to acquire (data before the STOP). The Circular Buffer length must thus be set taking into account that both the FERMI ADC and the internal Stop Processor Logic introduce a certain number of Clock cycles of latency.

The overall effect of the above is that if the User wants to acquire **m** samples before the occurrence of the STOP He/She must set a Circular Buffer Length (CBL) that is.

$$\text{CBL} = \text{BULENGTH} + 12 - m$$

where **BULENGTH** is the size of the FIFOs used in the module (4096) and **m** must satisfy the relation:

$$13 \leq m \leq \text{BULENGTH} + 12.$$

3.3.2. NUMBER OF SAMPLES TO ACQUIRE

The total number of samples to acquire must be the sum of the **m** samples already present in the Circular Buffer and the **l** samples after the STOP signal that the User wishes to acquire. The total number **n** to be written in the Sample Register (see § 4.3) is thus:

$$n = m + l.$$

When the content of the Circular Buffer (**m** samples already present + **l** newly incoming samples) is transferred to the Output Buffer, a Header is written in the Output Buffer, so the total number of words present in the Output Buffer will be **n+1** for each event.

3.3.3. ALMOST EMPTY FLAG

The Output Buffer Almost Empty (**OBAE**) is a number that can be set from 0 to 4095. The relevant flag (/AE, see 4.6) indicates, when set to 1, that the Output Buffer has at least a number **OBAE+1** of words to be read out. This information can be useful both in single readout or in Block Transfer readout modes:

- a) for single readout, the User could, e.g., set **OBAE** equal to the block length (**OBAE = n**), trigger the acquisition on the /Almost Empty bit in the Control & Status Register (see § 4.6) and perform a readout of the **n+1** words.
- b) for Block Transfer cycles, the User could set

$$\text{OBAE} = p \cdot (\text{BLT_LENGTH}) - 1$$

where **BLT_LENGTH** is the Block Transfer length (e.g. 256 byte = 64 words), trigger the acquisition on the /Almost Empty bit in the Control & Status Register (see § 4.6) and perform **p** Block Transfer cycles.

The /FIFO Empty bit available in the data (bit 30, see § 4.2) represents the status of the Output Buffer AFTER the current readout, i.e. after readout of the word that contains the /FIFO Empty bit itself. It is suggested NOT to use this bit to trigger the readout of the Output Buffer: this bit should be used only for diagnostic purposes.

3.3.4. ALMOST FULL FLAG

The Output Buffer Almost Full (**OBAF**) is a number that can be set from 1 to 4095. The relevant flag (/AF, see 4.6) indicates, when set to 1, that the Output Buffer has still sufficient space to store at least a number **OBAF+1** of words. This flag is used by the Control Logic to enter the BUSY state. The value of **OBAF** can be set taking into account the following:

1. the User can limit the Output Buffer length;
2. if the User wants to use all the Output Buffer length, care must be taken NOT to break up an event: if **OBAF** is set to **n**, with **n** = total number of samples to acquire (see § 3.3.2), a whole event will fit in the reserved space of the Output Buffer and thus no data will be lost.

3.4. PROGRAMMING THE MODULE

The User can program via VME the number of samples before the STOP (i.e. the Circular Buffer length), the total number of samples to be transferred in the Output Buffer (length of the temporal window) and two flags (Almost Empty, Almost Full) that allow to manage the data flow to and from the Output Buffer as described above in §3.3.

The Circular Buffer Length is set as a 12 bit word containing the desired length split in 2 parts (respectively 8 and 4 bits each) written in the FIFO Set Registers in 2 following accesses (confirming each time the set value via the Update FIFO Set Register).

The Almost Full and Almost Empty Flags in the Output Buffer are set as 12 bit words containing the desired Flag position split in 2 parts (respectively 8 and 4 bits each) written in

the FIFO Set Register in 2 following accesses (confirming each time the set value via the Update FIFO Set Register).

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
WORD 1	OBAE[7..0]															
WORD 2					OBAE[11..8]											
WORD 3	OBAF[7..0]								CBL[7..0]							
WORD 4					OBAF[11..8]								CBL[11..8]			

OBAE = OUTPUT BUFFER ALMOST EMPTY FLAG

OBAF = OUTPUT BUFFER ALMOST FULL FLAG

CBL = CIRCULAR BUFFER LENGTH

Fig. 3.1: Mod. V676 Buffer Flag Programming Words

In order to program the Module, either at Power-ON or for a change in the settings, the User must perform the following actions:

1. Perform a Reset (access to address Base + %10) or a VME SYSRES;
2. Write in the FIFO Setting Register (address Base + %0C) a word containing in the 8 uppermost bits (bits 8 to 15) the 8 lowermost bits (bits 0 to 7) of the Almost Empty Flag in the Output Buffer (see WORD 1 in Fig. 3.1);
3. Perform an access to the Update FIFO Set Register (address Base + %0E);
4. Write in the FIFO Setting Register (address Base + %0C) a word containing in the bits 8 to 11 the 4 uppermost bits (bits 8 to 11) of the Almost Empty Flag in the Output Buffer (see WORD 2 in Fig. 3.1);
5. Perform an access to the Update FIFO Set Register (address Base + %0E);
6. Write in the FIFO Setting Register (address Base + %0C) a word containing in the 8 uppermost bits (bits 8 to 15) the 8 lowermost bits (bits 0 to 7) of the Almost Full Flag in the Output Buffer and in the 8 lowermost bits (bits 0 to 7) the 8 lowermost bits (bits 0 to 7) of the Circular Buffer Length (see WORD 3 in Fig. 3.1);
7. Perform an access to the Update FIFO Set Register (address Base + %0E);
8. Write in the FIFO Setting Register (address Base + %0C) a word containing in the bits 8 to 11 the 4 uppermost bits (bits 8 to 11) of the Almost Full Flag in the Output Buffer and in the bits 0 to 3 the 4 uppermost bits (bits 8 to 11) of the Circular Buffer Length (see WORD 4 in Fig. 3.1);
9. Perform an access to the Update FIFO Set Register (address Base + %0E);
10. Write in the Samples Register (address Base + %04) a 12 bit word that contains the desired Number of Samples to be transferred from the Circular Buffer to the Output Buffer for a given STOP signal (allowed values 1 to 4095, see also § 4.3);
11. Set the Module to Acquisition Mode via the Control & Status Register (see § 4.6).

During all points of the above sequence of operations, the Module is in Busy status. Any STOP signal occurring does NOT increment the Rejected Events Counter.

This sequence of operations must be performed at Power-ON and each time the module must be re-programmed.

3.5. ACQUISITION SEQUENCE

When the module is switched back to the Acquisition Mode, it is ready to accept a STOP signal. In order to have correct timings, the User may wish to clear the Time Tag Counter with a CLEAR pulse in the relevant Front Panel connectors.

If the module is not BUSY, the leading edge of a pulse on the STOP input, synchronized with the Divided Clock cycle, starts the Control Logic, that performs the following operations:

- sets the module in the BUSY condition;
- starts the transfer of the selected number of samples in the Output Buffer;
- increments the Accepted Events Counter;

A suggested readout scheme may involve the use of the /Almost Empty bit in the Control & Status Register:

- wait until the /Almost Empty bit in the Control & Status Register is set to 1;
- read out from the Output Buffer **N** words, with $N \leq \text{OBAE}+1$ (see § 3.3.3)

3.6. CLOCK OPERATION

A DIP switch (S0) placed on the Printed Circuit Board (see Fig. 2.2) allows to select the CLOCK as being External (switch on EXT) or Internal (switch on INT).

The selected CLOCK is then fed to a Clock Division stage. Two DIP switches (S1) placed on the Printed Circuit Board (see Fig. 2.2) allow to insert a division by two of the Clock frequency. Each DIP switch inserts a division by 2. When both switches are inserted, the CLOCK frequency is divided by 4, if none is inserted the Clock frequency is unaltered. In particular, with the Internal CLOCK the User can obtain 40 MHz, 20 MHz and 10 MHz sample rates. Moreover, each divided Clock cycle will increment the Time Tag Counter.

The external clock (CLK input), must be a NIM signal on 50 Ω .

The clock selection scheme is shown in the following figure.




Fig. 3.2: Mod. V676 Clock Buffering Scheme

3.7. STOP LOGIC

The Stop Processor is synchronized with the Divided Clock. Due to this, the sampled waveform will have a jitter of $\pm\frac{1}{2}$ Divided Clock cycle with respect to the STOP signal.

The STOP can be either an external signal or an internal level generated by setting the first bit of the STOP Register (see § 4.10). Once set the bit in the STOP Register and after one Divided Clock cycle, the first bit of the STOP Register **MUST** be set back to 0.




Fig. 3.3: Mod. V676 STOP Logic

3.8. BUSY LOGIC

The module can enter a BUSY status for any of the following reasons:

1. a data transfer is taking place during an ordinary acquisition from the Circular Buffer to the Output Buffer;
2. the Output Buffer is Almost Full (bit 1 of Control & Status Register set to 0, see § 4.6);
3. the module is NOT in Acquisition Mode (see § 4.6).

When the module is BUSY it does not accept any STOP signals. If the BUSY status is due to point 1. or 2. above, the STOP signal will increment the Rejected Events Counter (see § 4.5).

If the BUSY status is due to point 3. above (i.e., the module is either in Programming Mode or in CAEN Internal Test), any STOP signal occurring does NOT increment the Rejected Events Counter.

3.9. TIME TAG COUNTER

Each pulse of the External or the Internal Divided CLOCK (SEE §3.6) increments a 30 bit Time Tag Counter. This Counter is set to 0 by an external CLEAR signal. The CLEAR must be a Std. NIM level: when present, its action is to hold to 0 the Counter and start it once released. The CLEAR is synchronized with the Divided Clock. Due to this, the occurrence of the physical Clear of the Time Tag Counter will have a jitter of 1 Divided Clock cycle with respect to the input CLEAR signal.

The Header that is written in the Output Buffer represents the absolute arrival time of the STOP signal with respect to the CLEAR release. In order to obtain the actual absolute time measurement of the arrival of the STOP signal, the User must use the following formula:

$$\text{Tabs} = (\text{TIME_TAG} - 3) * \text{DIV_CLOCK}$$

where **Tabs** is the absolute time, **TIME_TAG** is the Header value and **DIV_CLOCK** is the divided clock period. E.g., if the Header contains a value of 2500 and the Internal CLOCK is used with a DIV2 switch inserted (20 MHz sampling rate), the absolute time is

$$\text{Tabs} = (2500 - 3) * 50 \text{ ns} = 124850 \text{ ns}.$$

4. VME INTERFACE

4.1. ADDRESSING CAPABILITY

The V676 module works in A24/A32, D16/D32 mode. This implies that the module's address must be specified in a field of 24 or 32 bits. The Address Modifiers codes recognized by the module are:

AM=%3F: A24 supervisory block transfer (BLT)
 AM=%3D: A24 supervisory data access
 AM=%3B: A24 user block transfer (BLT)
 AM=%39: A24 user data access
 AM=%0F: A32 supervisory block transfer (BLT)
 AM=%0D: A32 supervisory data access
 AM=%0B: A32 user block transfer (BLT)
 AM=%09: A32 user data access

The module's Base Address is fixed by 4 internal rotary switches housed on two piggy-back boards plugged into the main printed circuit board.

The Base Address can be selected in the range:

% 00 0000 <-> % FF 0000 A24 mode
 % 0000 0000 <-> % FFFF 0000 A32 mode

The Address Map of the page is shown in Table 4.1.

Table 4.1: Address Map for the Mod. V676

ADDRESS	REGISTER/CONTENT	TYPE
Base + %FFFE . . Base + %14	Not used . . Not used	
Base + %12 Base + %10 Base + %0E Base + %0C Base + %0A Base + %08 Base + %06 Base + %04 Base + %00	Software STOP Register Reset Register Update FIFO Set Register FIFO Setting Register Control & Status Register Rejected Events Counter Accepted Events Counter Sample Register Output Buffer Register	read/write D16 read/write D16 read/write D16 write only D16 read/write D16 read only D16 read only D16 read/write D16 read only D32/BLT32




Fig. 4.1: Mod. V676 Base Address Setting

4.2. OUTPUT BUFFER REGISTER

(Base Address + %0, read only D32/BLT32)

This location allows to readout the data stored in the output Buffer. The structure of the Header is shown in Fig. 4.2. Its content is explained in §3.9.




Fig. 4.2: Mod. V676 Header Structure

/FIFO EMPTY 1= Output Buffer Not Empty
 0= Output Buffer Empty

The structure of the Data is shown in Fig. 4.3.




Fig. 4.3: Mod. V676 Data Structure

N.B.: The Sample ADC Data are stored in the Output Buffer with inverted bits: in order to obtain the actual converted value, the User must invert the bits' values for each bit.

4.3. SAMPLE REGISTER

(Base Address + %04, read/write D16)

It contains the number of samples that are transferred from the Circular Buffer to the Output Buffer for a given STOP signal. Allowed values: up to 4095.




Fig. 4.4: Mod. V676 Sample Register

4.4. ACCEPTED EVENTS COUNTER

(Base Address + %06, read only D16)

It contains the number of accepted events, i.e. the number of STOP signals occurred while the module is not Busy.

This Register must be read out only when no STOP signals are occurring.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				NUMBER OF ACCEPTED EVENTS											

Fig. 4.5: Mod. V676 Accepted Events Register

4.5. REJECTED EVENTS COUNTER

(Base Address + %08, read only D16)

It contains the number of rejected events, i.e. the number of STOP signals occurred while the module is Busy during the Acquisition Mode.

This Register must be read out only when no STOP signals are occurring.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
				NUMBER OF REJECTED EVENTS											

Fig. 4.6: Mod. V676 Rejected Events Register

4.6. CONTROL & STATUS REGISTER

(Base Address + %0A, read/write D16)

This Register contains 2 read/write bits that allow to set the module either in Programming or in Acquisition Mode, and 2 read only bits that allow to monitor the status of the Output Buffer. The Control bits are set to 1 after an access to the Reset Register, a VME SYSRES and at Power-ON (Programming mode).




Fig. 4.7: Mod. V676 Control & Status Register

/ALMOST EMPTY: if = 1 the Output Buffer has at least **OBAE+1** stored words (see §3.3.3).

/ALMOST FULL: if = 1 the Output Buffer has at least room for other **OBAF+1** words (see §3.3.4).

CONTROL: the status of these bits determines the operating mode of the module as follows.

Table 4.2: Mod. V676 Control Bits

CB0	CB1	MODE
0	0	ACQUISITION
1	1	BUFFERS PROGRAMMING
1	0	CAEN Internal Test Only (not allowed to User)
0	1	CAEN Internal Test Only (not allowed to User)

4.7. FIFO SETTING REGISTER

(Base Address + %0C, write only D16)

This Register allows to program the length of the Circular Buffer and the Almost Full and Almost Empty flags in the Output Buffer.

The programming sequences are fully described in § 3.4. Each write access to this Register must be followed by an access to the dummy Update FIFO Set Register at address Base + %0E to activate the desired settings.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
OUTPUT BUFFER SETTINGS								CIRCULAR BUFFER SETTINGS							

Fig. 4.8: Mod. V676 FIFO Setting Register

4.8. UPDATE FIFO SET REGISTER

(Base Address + %0E, read/write D16, dummy)

Any 16-bit access to this address confirms the settings performed in Programming Mode into the FIFOs (see § 3.4 for the complete Programming sequence).

4.9. RESET REGISTER

(Base Address + %10, read/write D16, dummy)

Any 16-bit read or write access to this address sets the module in the same configuration as the Power-ON status (see § 3.2).

4.10. SOFTWARE STOP REGISTER

(Base Address + %12, read/write D16)

This Register allows to generate an internal STOP signal for test purposes (see § 3.7). Only bit 0 of this Register is used (active high).




Fig. 4.9: Mod. V676 Software Stop Register

APPENDIX A: ELECTRICAL DIAGRAMS